

# Highlighting and selecting

To highlight an item, touch the screen lightly. To select an item or to place the cursor, click (press) the screen.

To cut or copy text and paste it into an application, simultaneously touch the screen before and after the text that you want to copy. Click the **cut** or **copy** icon at the bottom of the screen. Place the cursor where you want to insert the cut or copied text. Press the Menu key. Click Paste.



## Scrolling

To scroll down, slide your finger up. To scroll up, slide your finger down.

Scrolling up or down



## Moving between items

To move to the next item, slide your finger to the left quickly.

To move to the previous item, slide your finger to the right quickly.

#### Moving between items




# **Zooming and panning**

To zoom in to a picture or web page, click the screen. To zoom out from a picture or web page, press the key.

To pan a picture, slide your finger in any direction.







# Songs and videos

To pause or resume playing a song or video, press the **Mute** key.

To increase or decrease the volume, press the **Volume Up** key or the **Volume Down** key.

To play the next or previous song in a category, hold the **Volume Up** key or the **Volume Down** key.



#### Camera

To zoom in to or out from a subject, press the **Volume Up** key or the **Volume Down** key.

To lock focus on a subject before you take a picture, press the **Right Convenience** key halfway.

To take a picture, press the **Right Convenience** key.



## Menus and keys

To type a letter, click (press) the letter key.

To hide the keyboard, slide your finger down.

Hiding the keyboar



To open a menu in any application to access options and available actions, press the key.

To close a menu or move back a screen, press the key.

To lock the screen or device, press the **Lock** key.

To return to the Home screen, press the



For more navigation tips, see the setup wizard on your BlackBerry® device.

MAT-20890-001 Rev. 0021 PRINTSPEC-048 | 62/008 Research In Motion Limited. All rights reserved. BlackBerry®, RIM®, Research in Motion "SureType® and related trademarks, names and logos are the property of Research in Motion Limited and are registered and/or used in the US. and countries around the world. All other trademarks are the property of their respective owners. This documentation is provided "as is" and without condition, endorsement, guarantee, representation or warranty, or liability of any kind by Research in Motion Limited and its Affiliated companies, all of which are expressly disclaimed to the maximum extent